


D Gebrauchsanweisung
GB Operating instructions
F Notice d'emploi
NL Gebruiksaanwijzing
E Instrucciones de uso
P Instruções de uso
I Istruzioni per l'uso
DK Brugsanvisning
N Bruksanvisning
S Bruksanvisning
FIN Käyttöohje
H Használati utasítás
PL Instrukcja obsługi
CZ Návod k použití
SK Návod na použitie
SLO Navodilo za uporabo
HR Upute za upotrebu
RO Indicații de utilizare
BG Упътване за употреба
UA інструкції з використання
RUS Руководство по эксплуатации
RC 使用说明书


Bitron

18C, 24C, 36C, 55C, 72C, 110C












Technische Daten

D	Typ	Abmessungen	Gewicht	Nennspannung	Leistungsaufnahme	Betriebsdruck	UVC-Lampe	Kabellänge
GB	Type	Dimensions	Weight	Rated voltage	Power consumption	Operating pressure	UVC lamp	Cable length
F	Type	Dimensions	Poids	Tension nominale	Puissance absorbée	Pression de service	Lampe UVC	Longueur de câble
NL	Type	Afmetingen	Gewicht	Nominale spanning	Stroomverbruik	Werkingsdruk	UVC-lamp	Kabel lengte
E	Tipo	Dimensiones	Peso	Tensión nominal	Consumo de potencia	Presión de servicio	Lámpara UVC	Longitud del cable
P	Tipo	Dimensões	Peso	Tensão nominal	Consumo de potência	Pressão de trabalho	Lâmpada UVC	Comprimento do cabo
I	Tipo	Dimensioni	Peso	Tensione nominale	Potenza assorbita	Pressione d'esercizio	Lampada UVC	Lunghezza cavo
DK	Type	Dimensioner	Vægt	Netspænding	Effektforbrug	Driftstryk	UVC-lampe	Ledningslængde
N	Type	Mål	Vekt	Nettspenning volt	Inngangseffekt	Driftstrykk	UV-lampe	Kabelengde
S	Type	Mått	Vikt	Märkspänning	Effekt	Drifttryck	UVC-lampa	Kabelängd
FIN	Tyyppi	Mitat	Paino	Nimellijännite	Ototeho	Käyttöpaino	UVC-lamppu	Kaapelin pituus
H	Típus	Méreték	Súly	Névéleges feszültség	Teljesítményfelvétel	Üzemi nyomás	UVC-lámpa	Kábelhossz
PL	Typ	Wymiary	Ciężar	Napięcie znamionowe	Pobór mocy	Cisnienie robocze	Lampa ultravioletowa	Długość kabla
CZ	Typ	Rozměry	Hmotnost	Jmenovité napětí	Příkon	Provozní tlak	UVC zářivka	Délka kabelu
SK	Typ	Rozmery	Hmotnosť	Menovité napätie	Prikon	Prevádzkový tlak	UVC žiarivka	Dĺžka kábla
SLO	Tip	Dimenzije	Teža	Nazivna napetost	Mo	Delovni tlak	UVC-žarnica	Dožljina kabla
HR	Tip	Dimenzije	Masa	Nazivni napon	Snaga	Radni tlak	UVC žarulja	Duljina kabela
RO	Tip	Dimensiuni	Masă	Tensiune nominală	Putere	Presiune de funcționare	Lampă cu ultraviolete	lungime cablu
BG	Тип	Размери	Тегло	Номинално напрежение	Потребявана мощност	Работно налягане	Ултравioletова лампа	Дължина на кабелите
UA	Тип	Розміри	Вага	Номинальна напруга	Споживана потужність	Робочий тиск	Уль-трафіолетова лампа.	Довжина кабелю
RUS	Тип	Размеры	Вес	Номинальное напряжение	Потребляемые мощности	Рабочее давление/бар	Коротковолновая УФ-лампа	Длина кабеля
RC	型号	尺寸	重量	额定电压	消耗功率	运行压力 巴最大	紫外灯	电缆长度
BITRON	18C	440 x 180 x 185 mm	4,5 kg	220-240 V, 50 Hz	18 W	max. 0,5 bar	18 W, TC-L(UVC)	5,0 m
	24C				24 W		24 W, TC-L(UVC-C)	
	36C	603 x 180 x 185 mm	36 W		36 W, TC-L(UVC-C)			
	55C		55 W		55 W, TC-L(UVC-C)			
	72C	731 x 215 x 195 mm	72 W		2 x 36 W, TC-L(UVC-C)			
	110C		110 W		2 x 55 W, TC-L(UVC-C)			



	1	2	3	4	5	6	7	8
D	Wasserablauf UVC	Drehgriff	Wasserablauf Bypass	Wasserzulauf	Standfuß	Sicherheitsrasthebel	Schauglas	Gerätekopf
GB	Water outlet UVC	Rotary handle	Water outlet bypass	Water supply	Foot	Safetyengagement lever	Inspection glass	Unit head
F	Sortie d'eau UVC	Poignée tournante	Sortie d'eau Bypass	Arrivée d'eau	Pied-support	Lever à cran de sécurité	Verreregard	Tête d'appareil
NL	Waterafvoer UVC	Draaigreep	Waterafvoer bypass	Watertoevoer	Voet	Veiligheidshendel	Kijkglas	Kop van het apparaat
E	Salida de agua UVC	Puño giratorio	Salida de agua derivación	Entrada de agua	Pie	Palanca de retención de seguridad	Mirilla	Cabeza del equipo
P	Saída de água UVC	Manipulo giratório	Saída de água bypass	Entrada de água	Pé	Alavanca de segurança	Visor	Cabeça
I	Deflusso dell'acqua UVC	Manopola girevole	Deflusso dell'acqua bypass	Afflusso dell'acqua	Piede di supporto	Leva di sicurezza a scatto	Splia di ispezione	Testa dell'apparecchio
DK	Vandaflob UVC	Drejehåndtag	Vandaflob bypass	Vandtiløb	Fod	Sikkerhedslåsarm	Skueglas	Apparathoved
N	Vannavlop UVC	Håndtak	Vannavlop bypass	Vanntillop	Fot	Sikkerhetshåndtak	Seglass	Apparatet
S	Vattenutlopp UVC	Vred	Vattenutlopp bypass	Vattentlopp	Uppställningsfot	Säkerhetsknapp	Inspektionsglas	Apparatens ovan del
FIN	Vedenpoisto UVC	Kiertokahva	Vedenpoisto ohitus	Vedentulo	Jalusta	Turvallikutusvipu	Tarkastuslasi	kotelon pää
H	Viz-leeresztő UVC	Forgókar	Viz-leeresztő bypass (áteresztő szelep)	Viz-betáplálás	Lábazat	Biztonsági rögzítőkar	Betekintő ablak	Készülékfej
PL	Odpływ wody ultrafiolet	pokrećło	odpływ wody obejściowy	dopływ wody	podpórka	dźwignia zabezpieczająca z zapadką	wziernik	glowica urządzenia
CZ	Odtok vody UVC	Otočné držadlo	Odtok vody bypass	Přítok vody	Palka	Bezpečnostní páka se západkou	Inspekční sklo	Hlava přístroje
SK	Odtok vody UVC	Otočné držadlo	Odtok vody bypass	Pritok vody	Pátka	Bezpečnostná páka so západkou	Inšpekčné sklo	Hlava prístroja
SLO	Vodni-odtok UVC	Vrtil roaj	Vodni-odtok "Bypass"	Vodni-dotok	Podstavek	Varnostniv-zvod	Vidno steklo	Glava naprave
HR	Odvod vode UVC	Okratna ručka	Odvod vode bajpas	Dovod vode	Stopalo	Sigurnosna preskočna poluga	Kontrolno staklo	Glava uređaja
RO	Componentă scurgere apă ultraviolet	Măner rotitor	Bypass scurgere apă	Componentă admisie apă	Picior de sprijin	Manetă de siguranță	Geam de control	Capul aparatului
BG	Изход за водата-облачница с ултравиолетови лъчи	Въртяща се ръчка	Изход за водата-Байпас	Вход за водата	Краче	Обезопасващ фиксатор сирац пост	Прозорче за контрол	Глава на уреда
UA	Стік води УФ	Обертюва ручка	Стік води байпас	Водоприймальний канал	Опора	Важіль- безпеки	Оглядове скло	Головка пристрою
RUS	Сливная линия, коротковолн. УФ	Поворотный рычаг	Сливная линия, байпас	Подан воды	Опорная лапка	Предохранительный фиксаторный рычаг	Смотровое стекло	Головка прибора
RC	出水口紫外线	转动手柄	旁路出水口	进水口	支脚	安全制动手	观察玻璃	机头



Störungen

Störung	Ursache	Abhilfe
Wasser nicht klar	<ul style="list-style-type: none"> - UVC-Lampe leuchtet nicht. - Reinigungsrotor/Quarzglasrohr verschmutzt - Fördermengen Pumpe, Gerät nicht korrekt - Schwebendes Material braun, sinkt zu Boden - Teich extrem verschmutzt - Lampe hat keine UVC-Leistung - BypassEinstellung nicht in Ordnung 	<ul style="list-style-type: none"> - Elektrische Anschlüsse prüfen - Reinigen - Siehe Installation - Algen und Blätter entfernen, Schmutzeinfall verhindern - Wasserwerte prüfen, Wasserwechsel - Lampe prüfen und Lampe nach 8000/h wechseln - Einstellung prüfen, Pumpenleistung beachten
An den Wasserabläufen fließt kein Wasser	<ul style="list-style-type: none"> - Strömungsdüse verstopft - Wasserabläufe verdrückt 	<ul style="list-style-type: none"> - Netzstecker ziehen, Pumpe ausschalten. - Strömungsdüse bzw. Wasserabläufe säubern
Wasserzulauf	<ul style="list-style-type: none"> - Rotor dreht nicht 	<ul style="list-style-type: none"> - Strömungsdüse einsetzen, da Wasserdruck zu gering

Information about this operating manual

Please read the operating instructions and familiarise yourself with the unit prior to using it for the first time. Adhere to the safety information for the correct and safe use of the unit.

Intended use

The use of the Bitron, termed the 'unit' in the following is restricted for cleaning normal pond water.

Use other than that intended

Danger to persons can emanate from this unit if it is not used in accordance with the intended use and in the case of misuse. If used for purposes other than than intended, our warranty will become null and void general operating permit.

CE Manufacturer's Declaration

We declare conformity in the sense of the EC directive, EMC directive (89/336/EEC) as well as the low voltage directive (73/23/EEC). The following harmonised standards apply:

EN 60335-1, EN 60598-1, EN 60598-2-1, EN 55015, EN 61000-3-2, EN 61000-3-3, EN 61547

Signature:



Safety information

OASE has manufactured this unit according to the state of the art and the valid safety regulations. Despite of this, danger for persons and assets could emanate from this unit, if it is used inappropriately or for purposes other than those intended, or if the safety information is ignored.

For safety reasons, children and young persons under 16 years of age, who cannot recognise possible danger or who are not familiar with these operating instructions, are not permitted to use this unit!

Please keep these operating instructions in a safe place! Also hand over the operating instructions when passing the unit on to a new owner. Ensure that all work with this unit is only carried out in accordance with these instructions.

The combination of water and electricity can imply a high risk to life and limb, if the unit is incorrectly connected or inappropriately handled.

Attention! Dangerous ultra-violet radiation.

The radiation of the UVC lamp is dangerous for eyes and skin! Never operate the lamp of the unit outside of its housing and never without the cleaning rotor, knowing that the latter provides an eye protection from UVC radiation.

For your own safety, consult a qualified electrician when you have questions or encounter problems!

Never immerse the unit in water! Always disconnect the power supply of all units located in water and of this unit prior to performing work on the unit! Only operate the unit when plugged into an earthed socket. The latter must have been installed in accordance with the valid national regulations. Ensure that the protective earth wire is led to the unit. Never use installations, adapters, extension or connection cables without protective contact! The cross section of supply connection cables must not be smaller than the rubber cables identified with H05 RN-F. Extension cables must meet DIN VDE 0620. Ensure that the unit is supplied via a fault current protection (FI or RCD) with a reference fault current of 30 mA maximum. Never use the unit when persons are in the water! Never use the pump for fluids other than water! Never open the unit housing or its attendant components, unless this is explicitly mentioned in the operating instructions. Never run the unit without water!

Important! The unit is equipped with permanent magnets. The magnetic field can influence pacemakers.

Never operate the unit if the cable, inspection glass or housing are defective! Disconnect the power! Do not carry or pull the unit by the connection cable. Electrical installations at garden ponds and swimming pools must meet the international and national regulations valid for installers. Compare the electrical data of the supply with those on the unit type plate.

For your own safety, consult a qualified electrician when you have questions or encounter problems! Protect the connection cable when burying to stop damage. Only use cables approved for outside use. Protect the power connection from moisture.

Installation

Install the unit horizontally, with its feet down (C). Choose a place for the unit which cannot be flooded! Minimum distance between the unit and the pond: 2 m. Install the unit so that it is not exposed to direct sun radiation. Ensure that the unit will never run without water!

During installation (A and B), observe the correct position of the flat seal (2) and the O ring (1).

Start-up

Switch on the pump and wait until the unit is filled with water. Check all connections for leaks. Connect the power supply. Check the function of the UVC lamp and the cleaning rotor at the inspection glass (D-7). Both functions are OK, when an alternating bright/dark blue light is visible.

Bypass

The water flow can be controlled by the bypass system. The water flows into the unit from the supply (D-4). Depending on the setting, part of the water can drain directly through the water outlet (D-3) whereas the other part is radiated with UVC light in the unit and drains via the water outlet (D-1). Optimum cleaning is only achieved when the water throughflow is correctly set. The correct setting complies with delivery rate (l/h) of your pump; for this purpose, both rotary handles (D-3, D-4) must be set to the same delivery rate.

Changing the UVC lamp

Change the UVC lamp after approx. 8,000 operating hours (G).

Adhere to the safety information given above! Press the safety engagement lever (D-6), turn the unit head in the direction of the arrow up to the stop and carefully pull out including the cleaning rotor. Remove the cleaning rotor from the quartz glass. Undo the clamping screw (H) by turning counter-clockwise, and remove the quartz glass including the O ring with a slight turning movement.

Pull out the UVC lamp (F) and replace. The rubber band on the original UVC lamp was intended as transport security and need not be replaced. The UVC lamp only lights up after the complete re-assembly of the unit.

Important! Only use lamps with the designation and rating

[W = Watt] of which comply with those on the type plate.

Remove the O ring from the quartz glass, clean and check for damage. Clean the quartz glass outer face with a moist cloth. Check the quartz glass for damage prior to refitting. Refit the O ring on the quartz glass, insert the quartz glass in the unit head against the stop. Press the O ring into the gap between unit head and quartz glass. The O ring will be pressed into its correct final position by the action of the clamping screw. Screw in the clamping screw clockwise (H) against the stop. Slide the cleaning rotor onto the quartz glass. Check the O ring at the unit head for damage and correct seating. Ensure that the O ring is seated in front of the recess at the unit head (I). Carefully push the unit head into the housing. During this action, the cleaning rotor and the quartz-glass are pushed into the rear mounting inside the housing. The inner marking at the unit head must coincide with the marking (G) on the housing. Carefully push the unit head into the housing up against the stop. Note: If the unit head cannot be completely pushed on, check that the clamping screw is fully screwed in against the stop. Turn the unit head opposite to the arrow direction against the stop while exerting slight pressure (markings on the unit head and the housing are aligned). Ensure that the safety engagement lever engages. Start up the pump first, then connect the power supply.

Changing the cleaning rotor

The cleaning rotor has to be replaced when the racing surface is worn down to the wear marking ridges.

Adhere to the safety information given above! Press the safety engagement lever, turn the unit head (G) in the direction of the arrow up to the stop and carefully pull out including the cleaning rotor. Remove and replace the cleaning rotor from the quartz glass. Re-assemble in the reverse order, in the same manner described under changing the UVC lamp. Start up the pump first, then the unit.

Cleaning**Automatic cleaning**

The cleaning rotor is continuously guided through the water flow around the quartz glass tube. The unit must run permanently. Operation in intervals could lead to stubborn soiling and furring which have to be removed by manual cleaning.

Cleaning the quartz glass tube (G)

Adhere to the safety information given above! Press the safety engagement lever, turn the unit head in the direction of the arrow up to the stop and carefully pull out including the cleaning rotor. Remove the cleaning rotor from the quartz glass and clean thoroughly. Also thoroughly clean the inner and outer surfaces of the housing. Clean the quartz glass using a moist cloth, and slide the cleaning rotor onto the quartz glass. Re-assemble in the reverse order, in the same manner described under changing the UVC lamp. Start up the pump first, then connect the power supply.

Cleaning the inspection glass (J)

Adhere to the safety information given above! Press the safety engagement lever, turn the unit head in the direction of the arrow up to the stop and carefully pull out including the cleaning rotor. Clean the inspection glass inner and outer surfaces. Note: The inspection glass cannot be removed! Re-assemble in the reverse order, in the same manner described under changing UVC lamp. Start up the pump first, then connect the power supply.

Storage/Shutting down over the winter

Remove the unit at temperatures below zero. Clean the unit thoroughly, check for damage and store in a dry and frost-free environment.

Wearing parts

The UVC lamp, the quartz glass, the clamping screw and the rotor are wear parts and not subject to warranty.

Disposal

Dispose of the unit in accordance with the legal regulations when the power cable is defective. The UVC lamp needs special disposal. Ask your specialist dealer.

Trouble shooting

Trouble shooting	Cause	Remedy
Cloudy water	<ul style="list-style-type: none"> - UVC lamp does not light up. - Cleaning rotor/quartz glass tube soiled - Incorrect pump flow rate (unit) - Brown suspended material, deposits at the bottom - Pond extremely dirty - Lamp has no UVC capacity - Incorrect bypass adjustment 	<ul style="list-style-type: none"> - Check electrical connections - Cleaning - See installation - Remove algae and leaves, prevent the ingress of dirt - Check water values, change the water - Check the lamp, change the lamp after 8,000/h - Check the setting, note the pump capacity
No water flow at the water outlets	<ul style="list-style-type: none"> - Flow nozzle blocked - Water outlets dirty 	<ul style="list-style-type: none"> - Disconnect power supply, switch off the pump. - Clean the flow nozzle or the water outlets
Water supply	<ul style="list-style-type: none"> - Rotor does not turn 	<ul style="list-style-type: none"> - Insert a flow nozzle because of insufficient water pressure

Remarques relatives à cette notice d'emploi

Avant la première utilisation, lire attentivement cette notice d'emploi et se familiariser avec l'appareil. Respecter impérativement les indications de sécurité relatives à une utilisation correcte et en toute sécurité.

Utilisation conforme à la finalité

La gamme Bitron, nommée par la suite «appareil», est uniquement destinée à la filtration d'eau normale de bassin.

Utilisation non conforme à la finalité

En cas d'utilisation non conforme à la finalité et de manipulation non appropriée, des risques pour les personnes peuvent en résulter. Toute utilisation non conforme à la finalité entraîne l'annulation de notre responsabilité ainsi que de l'autorisation d'exploitation générale.

Déclaration du fabricant CE

Noharmonisées suivantes ont été appliquées :

EN 60335-1, EN 60598-1, EN 60598-2-1, EN 55015, EN 61000-3-2, EN 61000-3-3, EN 61547

Signature : 

Indications de sécurité

La société **OASE** a construit cet appareil selon l'état actuel des connaissances techniques et les consignes de sécurité en vigueur. Toutefois des dangers pour les personnes et les biens peuvent émaner de cet appareil lorsque celui-ci est utilisé de manière non appropriée voire non conforme à sa finalité ou lorsque les informations de sécurité ne sont pas respectées.

Pour des raisons de sécurité, les enfants et les mineurs de moins de 16 ans ainsi que les personnes n'étant pas en mesure de reconnaître les dangers ou n'ayant pas pris connaissance de cette notice d'emploi ne sont pas autorisés à utiliser cet appareil !

Prière de conserver soigneusement cette notice d'emploi ! Lors d'un changement de propriétaire, transmettre également cette notice d'emploi. Tous les travaux effectués avec cet appareil devront être exécutés conformément aux directives ci-jointes.

La combinaison d'eau et d'électricité peut entraîner des dangers sérieux pour la santé et la vie des personnes lors d'une utilisation avec des raccordements non conformes ou une utilisation inappropriée.

Attention ! Rayonnement ultraviolet dangereux !


Le rayonnement de la lampe UVC est dangereux pour les yeux et la peau ! Ne jamais utiliser la lampe de l'appareil hors du carter, et jamais sans rotor de nettoyage car celui-ci protège la vue contre le rayonnement UVC.

En cas de questions et de problèmes, prière de vous adresser à un électricien et ce, pour votre propre sécurité !

Ne jamais plonger l'appareil sous l'eau ! Toujours retirer la prise de secteur de tous les appareils se trouvant dans l'eau et de cet appareil avant de procéder à des travaux sur cet appareil ! Utiliser cet appareil uniquement sur une prise de courant équipée d'un contact de mise à la terre. Cette dernière devra être installée selon les règlements nationaux en vigueur. Prière de s'assurer que la prise de terre soit connectée jusqu'à l'appareil. Ne jamais utiliser d'installations, d'adaptateurs, de rallonges ou de lignes de raccordement sans contact de mise à la terre ! La section des lignes de raccordement du secteur ne doit pas être inférieure à celle des câbles souples sous caoutchouc portant l'identification H05 RNF. Les lignes de rallonge doivent être conformes à DIN VDE 0620. Prière de s'assurer que l'appareil est alimenté via un dispositif de sécurité à courant de défaut (FI, voire RCD) avec un dimensionnement de courant de défaut inférieur à 30 mA. Ne pas utiliser l'appareil lorsque des personnes se trouvent dans l'eau ! Ne jamais refouler des liquides autres que de l'eau ! Ne jamais ouvrir le carter de l'appareil ou des parties y appartenant si cela n'est pas expressément indiqué dans la notice d'emploi. Ne jamais utiliser l'appareil sans un débit d'eau !

Important !: L'appareil est équipé d'aimants permanents. Le champ magnétique peut influencer un stimulateur cardiaque.


Ne pas utiliser l'appareil en cas de câble, de verre-regard ou de carter défectueux ! Retirer la prise de secteur ! Ne pas porter ni tirer l'appareil par le câble de raccordement. Les installations électriques des étangs de jardins et des bassins doivent correspondre aux règlements d'installation internationaux et nationaux. Comparer les données électriques du réseau d'alimentation avec celles indiquées sur la plaque signalétique. En cas de questions et de problèmes, prière de vous adresser à un électricien et ce, pour votre propre sécurité ! Poser la ligne de raccordement de manière protégée afin



Achtung!
Attention!

D	Achtung! Bei keiner Funktion des UVC Lichtes die Lampen auf festen Sitz kontrollieren.
GB	Attention! Check the lamps for tight seating, if the UVC light does not function.
F	Attention! Au cas où la lumière UV n'apparaît pas, contrôler le bon positionnement des lampes.
NL	Let op! Als het UVC-licht niet werkt, controleer dan of de lampen goed vastgedraaid zijn
E	Cuidado! S ni funciona la luz UVC controle el asiento fijo de las lámparas.
P	Cuidado! Caso a luz UVC não funcione, verifique se as lâmpadas ficam bem fixas no asquilha.
I	Attenzione! In caso di non funzionamento della luce UVC controllare il fissaggio delle lampade.
DK	OBS! Kontrollér lamperne for sikkert fæste, hvis UVC-lyset ikke virker.
N	NB! Hvis UVC-lyset ikke virker, kontrollér at lampene sitter som de skal.
S	Obs! Om UVC-ljuset inte fungerar måste du kontrollera att lamporna sitter fast.
FIN	Huomio! UVC-valon toimintahäiriön johdosta tarkasta lampujen pitävää kiinnitystä.
H	Figyelem! Ha az UVC megvilágítás nem működik, ellenőrizze a lámpák megfelelő illeszkedését.
PL	Uwaga! W przypadku braku światła ultrafioletowego skontrolować prawidłowe osadzenie żarówek.
CZ	Pozor! Při žádné funkci UVC světla nekontrolovat upevnění lamp.
SK	Pozor! Pri žiadnej funkcii UVC svetla nekontrolovat' upevnenie žiaroviek.
SLO	Pozor! Pri nobeni funkciji UVC svetlobe ne preverjajte, kako trdno je žarnica nameščena.
HR	Pozor! Ukoliko UVC svjetlo ne radi provjerite jesu li žarulje dobro pričvršćene.
RO	Atenție! Nu verificați fixarea bună a becurilor în timpul nici unei funcțiuni a lămpii UVC.
BG	Внимание! Когато UVC – светлината (ултравиолетовата светлина) не функционира, проверете дали лампите са прилегли и затегнати правилно.
UA	Увага! Не перевіряйте кріплення лампи за умови ультрафіолетового світла.
RUS	Внимание! Проверить плотность установки ламп при полностью отключенном коротковолновом УФ-свете.
RC	小心! 在紫外线灯不工作时, 请检查灯的连接是否牢固。

Pos	18C	24c	36C	55C	72C	110C
1	56236	56237	55432	56636	2x55432	2x55636
2	35068	35068	35069	35069	35327	35327
3	35111	35111	35112	35112	35329	35329
4	35028	35028	35028	35028	35335	35335
5	22853	22835	22853	22853	22853	22853
6	35090	35090	35091	35091	35321	35321
7	35092	35092	35092	35092	35092	35092
8	35113	35113	35113	35113	35330	35330
9	26041	26041	26042	26042	27118	27118
10	26143	26143	26143	26143	27117	27117
11	24850	24850	24850	24850	27148	27148
12	35116	35117	35118	35119	35331	35332
13	35120	35121	35122	35123	35333	35334



Oase
LIVING WATER

OASE GmbH
Tecklenburger Str. 161
48477 Hörstel
Germany

www.oase-livingwater.com